
## DART (Derailment Analysis Research Tool)

When a derailment occurs, DART is a tool used by railroads to request and receive a spreadsheet of components and equipment associated to the equipment ID for one or more railcars, up to 200 at one time. See <u>Accessing DART</u> to learn how to access to DART.


Use this procedure to request and receive component data for derailment purposes:

- 1. Sign in to Launch Pad and navigate to Equipment Health View.
- 2. From the Equipment Health View menu bar, select **D.A.R.T.**




- 3. Enter one or more valid Equipment ID(s) (up to 200) by following these guidelines:
  - a. The more equipment entered, the longer the request will take to return. 200 equipment IDs submitted in one request may take up to an hour.
  - b. If the request takes less than 30 seconds, you'll receive a link in the success message as shown below and an email with the link to download the spreadsheet. If the request takes longer than 30 seconds, you'll only receive the link to the spreadsheet by email.
  - c. Equipment IDs can be entered as comma, line and space delimited. Leading zeros are optional.
  - d. DART will not accept a range of equipment IDs using a hyphen.
  - e. Each equipment ID should be a string with no spaces. DART will not accept an equipment ID with a space between the mark and the equipment number.
  - f. The report will show blank rows for any invalid equipment IDs. If other valid equipment IDs are submitted at the same time, you'll receive data for all the valid equipment IDs.
  - g. DART will return an error when the request does not contain any valid equipment IDs.

## 4. Select Submit Request.




## DART (Derailment Analysis Research Tool)

5. If the request has valid equipment IDs and takes less than 30 seconds to run, you'll receive a success message with a shareable **Click here to download** link (shown above) to download the spreadsheet. Example spreadsheet:



6. You'll receive an email that contains the download link. This link can be shared with others at your discretion whether or not they have access to DART. The link is available and shareable for 90 days after the request. After 90 days the original link expires, and a user with DART access will need to follow the steps above again for a new link.



## Accessing DART

DART requires SSO access as defined in Railinc's <u>Single Sign-On User Guide</u>. Once you have SSO access, request access in the Launch Pad to the Equipment Health View (EHV) role of **EHV Generic Access**. For details and questions about EHV, see the <u>EHV User Guide</u>.

Permission to access DART from within EHV is granted by Railinc. For DART permission, contact the Customer Success Center toll-free by phone at 877- RAILINC (1-877-724-5462) or send an email directly to <a href="mailto:csc-arillinc.com">csc@railinc.com</a>.

Legal Disclaimer: Any actions taken in reliance on or pursuant to this document are subject to Railinc's Terms of Use, as set forth in https://public.railinc.com/terms-use, and all AAR rules.