

Original Cost Self-Service User Guide



© 2023 Railinc. All Rights Reserved.

Last Updated: November 2023

Table of Contents

Learning about Original Cost Self-Service.....	1
Overview.....	1
OCSS Process for New and Existing Superstructures	1
OCSS Process for Rebuilt Superstructures	2
OCSS Process for Adding Addition and Betterment (A&B) data for Superstructures.....	3
System Requirements.....	3
Accessing the Railinc Customer Success Center	3
Getting Started	4
Registering to Use Railinc SSO	4
Requesting Access to OCSS	4
Logging In.....	5
Logging Out	6
Searching for and Viewing Cost Information	7
Viewing OCSS Status Information	7
Searching for Superstructures	8
Viewing Search Results	9
Entering Cost Information.....	13
Entering Original Cost Information	13
Entering Addition and Betterment (A&B) Information.....	15
Entering Rebuilt Cost Information.....	17

List of Exhibits

Exhibit 1. User Roles and Tasks	4
Exhibit 2. OCSS Request Permission (Showing the OCSS Roles)	5
Exhibit 3. Railinc Welcome Page	5
Exhibit 4. Railinc Launch Pad	6
Exhibit 5. OCSS Home Page	6
Exhibit 6. OCSS Home Page	7
Exhibit 7. OCSS Management Page (Showing the Search Equipment Criteria Fields)	8
Exhibit 8. OCSS Management Page (Showing the Search Equipment Result Fields)	9
Exhibit 9. Comment History Popup	10
Exhibit 10. Enter Cost Popup (Showing the Enter Cost Section)	13
Exhibit 11. Enter Cost Popup (Showing the Upload Documents Section)	14
Exhibit 12. Enter Cost Popup (Showing the Upload Documents Section Completed).....	14
Exhibit 13. Enter Cost Success Message	15
Exhibit 14. Enter Cost Popup (Showing the Enter Cost Section)	15
Exhibit 15. Enter Cost Popup (Showing the Upload Documents Section)	16
Exhibit 16. Enter Cost Popup (Showing the Upload Documents Section Completed).....	16
Exhibit 17. Enter Cost Success Message	16
Exhibit 18. Enter Cost Popup (Showing the Enter Cost Section)	17
Exhibit 19. Enter Cost Popup (Showing the Upload Documents Section)	18
Exhibit 20. Enter Cost Popup (Showing the Upload Documents Section Completed).....	18

Learning about Original Cost Self-Service

Original Cost Self-Service (OCSS) is an application that enables superstructure owners to confirm and store original and rebuilt cost data in a centralized location. OCSS facilitates the audit process so that the audit team may review original and rebuilt cost documents for superstructures before the values are updated in Umler®.

Overview

OCSS serves as a document repository of invoices and other documents to support the cost value of a non-integrated superstructure (car rack attached to a vehicular flat car). It facilitates the audit process for superstructures and ensures that superstructure owners provide accurate cost information for original and rebuilt superstructures.

This document describes how to use OCSS through the following major sections:

- [“Getting Started”](#) on page 4 describes how to access and log in to the system.
- [“Searching for and Viewing Cost Information”](#) on page 7 describes how to view the number of your mark’s superstructures by status.
- [“Entering Cost Information”](#) on page 13 describes how to enter cost information for new and rebuilt superstructures.

Note: Entering cost information requires the OCSS User permission.

For additional information, contact the Railinc Customer Success Center (see [“Accessing the Railinc Customer Success Center”](#) on page 3).

OCSS Process for New and Existing Superstructures

Superstructures (also known as “car racks”, or simply “racks”) are required to be entered into Umler. This is done by the owner of the vehicular flat car to which the superstructure is attached. Once a superstructure is entered into Umler, the owner of the superstructure (which may be different than the owner of the vehicular flat car) can locate the superstructure (see [“Searching for Superstructures”](#) on page 8) in OCSS and provide original cost documentation for new and rebuilt superstructures and create Additions and Betterments (A&B). They can manage their pending and rejected submissions and work with the Railinc audit team to address any issues.

Knowing accurate cost information is important to superstructure owners because the cost information determines how much money they can receive for the use of the superstructure according to Appendix T in [AAR Circular OT-10](#).

Important: Upon deployment of OCSS on November 28, 2023, all existing superstructures were updated in Umler to have the status of “Verified”. Any superstructures added after the deployment of OCSS are initially entered with a status of “Estimated” and are required to be audited before they are granted “Verified” status.

The following steps describe the OCSS process for new and existing superstructures:

1. A user adds a superstructure to a vehicular flat car in Umler in “Estimated” status.
2. OCSS connects to Umler in real-time and obtains cost information.
3. A user can access OCSS and provide documentation supporting the cost information they submitted in Umler. They can update the cost information in OCSS if needed, provided that the submitted documentation supports the cost update. The Umler status remains at “Estimated”, but the OCSS status is changed to “Pending”.
4. An auditor reviews the submitted cost information and supporting documentation and approves or rejects the submission.
5. The submitter is notified by email of the results of the audit.
 - If approved, the values submitted in OCSS are updated in Umler and the superstructure status is changed to “Verified” in Umler.
 - If rejected, the auditor must provide a reason for the rejection, and the status is changed to “Rejected” in OCSS. A comment is also added to the rejected equipment. The submitter is required to address any issues identified by the auditor.

Note: Any pending or rejected submission may be deleted by the submitter and then resubmitted at a later time.

OCSS Process for Rebuilt Superstructures

The following steps describe the OCSS process for rebuilt superstructures:

1. A user adds a rebuilt date to a superstructure in Umler. The superstructure status in Umler reverts to “Estimated”.
2. OCSS connects to Umler in real-time and obtains the original cost information.
3. A user can access OCSS and provide rebuild cost information and supporting documentation. The Umler status remains at “Estimated”, but the OCSS status is changed to “Pending”.
4. An auditor reviews the submitted rebuild cost information and supporting documentation and approves or rejects the submission. The submitter is notified by email of the results of the audit.
 - If approved, the values submitted in OCSS are updated in Umler and the superstructure status is changed to “Verified” in Umler. Additionally, if the superstructure has Addition and Betterment (A&B) information, the A/B information is deleted in Umler (as this is included as part of the rebuild cost calculation).
 - If rejected, the auditor must provide a reason for the rejection, and the status is changed to “Rejected” in OCSS.
5. The submitter is required to address any issues identified by the auditor.

OCSS Process for Adding Addition and Betterment (A&B) data for Superstructures

OCSS is also used for adding Addition and Betterment (A&B) data for superstructures. A user searches for superstructures owned by their mark and updates the A&B values (three fields). After audit and approval, the A&B data entered into OCSS is added to Umler.

System Requirements

For information about the system requirements of Railinc web applications and for information about downloading compatible web browsers and file viewers, refer to the [Railinc UI Dictionary](#).

Accessing the Railinc Customer Success Center

The Railinc Customer Success Center provides reliable, timely, and high-level support for Railinc customers. Representatives are available to answer calls and respond to emails from 7:00 a.m. to 7:00 p.m. Eastern time, Monday through Friday, and provide on-call support via pager for all other hours to ensure support 24 hours a day, 7 days a week. Contact us toll-free by phone at 877-RAILINC (1-877-724-5462) or send an email directly to csc@railinc.com.

Getting Started

OCSS uses Railinc Single Sign-On (SSO) to manage permissions. To access SSO, view the Railinc portal at <http://www.railinc.com> and select **Customer Login** at the top right of the page.

Registering to Use Railinc SSO

Each OCSS user must register to use Railinc Single Sign-On (SSO). If you are not already registered, refer to the [Railinc Single Sign-On and Launch Pad User Guide](#) for more information. Once you have completed SSO registration, request access to OCSS within SSO.

Requesting Access to OCSS

After you receive authorization to use Railinc SSO, you must request access to OCSS by following instructions in the [Railinc Single Sign-On and Launch Pad User Guide](#).

Your level of access and authorization for OCSS is determined when you request access through Railinc SSO. [Exhibit 1](#) shows a complete list of OCSS roles as seen in SSO.

Exhibit 1. User Roles and Tasks

Role	Description
OCSS Company Admin	Company Administrator who will manage the assignment of OCSS-related roles for their company. This user will receive emails for requested permissions for their respective company and must grant permission as determined by their respective company.
OCSS User	Original Cost Self-Service user with permissions reflecting a stencil mark owner. May create and manage original and rebuilt cost data, which includes submitting and searching original and rebuilt cost data.
Original Cost Self-Service Read-only User	Original Cost Self-Service user with permissions reflecting a stencil mark owner. May search for and download data from the search functionality.

Your assigned user role determines what functions you can perform. User roles are assigned by Railinc through the Single Sign-On interface ([Exhibit 2](#)).

Exhibit 2. OCSS Request Permission (Showing the OCSS Roles)

Original Cost Self-Service
Provides the North American Rail Industry with a centralized repository for superstructure Original and Rebuilt Cost documentation.

1 Select Roles 2 Confirm 3 Done

OCSS Company Admin (MARK required)
Company Administrator who will manage the assignment of OCSS related roles for their company. This user will receive emails for requested permissions for their respective company and must grant permission as determined by their respective company.

OCSS User (MARK required)
Original Cost Self-Service user with permissions reflecting a stencil mark owner. May create and manage Original and Rebuilt cost data which includes submitting and searching original and rebuilt cost data.

Original Cost Self-Service Read-only User (MARK required)
Original Cost Self-Service user with permissions reflecting a stencil mark owner. May search for and download data from the search functionality.

Comments... 0/255


Choose your role(s) and enter the mark for your railroad. Select **Next** to proceed. Once you receive email notification of access, you can log in and begin using OCSS.

Logging In

Use the following procedure to log into OCSS:


1. Open your internet browser.
2. Enter the following URL: <http://www.railinc.com>. The Railinc Welcome page is displayed ([Exhibit 3](#)).

Exhibit 3. Railinc Welcome Page




3. Select **Customer Login** at the top right. The Railinc Account Access panel is displayed.
4. In the Account Access panel, enter your **User ID** and **Password**. Select **Sign In**. The Railinc Launch Pad is displayed ([Exhibit 4](#)).

Exhibit 4. Railinc Launch Pad



5. Under **My Applications**, select **OCSS** (you may need to scroll down). The OCSS Home page is displayed ([Exhibit 5](#)).

Exhibit 5. OCSS Home Page



The OCSS Home page contains three major categories of OCSS and Umler status information. (see “[Searching for and Viewing Cost Information](#)” on page 7 for more information).

OCSS has a menu bar that contains the following options:

Home Return to the OCSS Home page after viewing another OCSS page. This page displays various status values (see “[Searching for and Viewing Cost Information](#)” on page 7).

Management Enter cost information for new and rebuilt superstructures (see “[Entering Cost Information](#)” on page 13).

User Guide View the *Original Cost Self-Service User Guide*.

Logging Out

Select the **Sign Out** link to end an OCSS session.

Searching for and Viewing Cost Information


The OCSS application enables you to view and enter cost information for new and rebuilt superstructures.

Note: Only users with the OCSS User permission can enter cost information. Other users have read-only access and can only search, view, and download information.

Viewing OCSS Status Information

When first opened, the OCSS Home page is displayed, which shows status information about superstructures ([Exhibit 6](#)).

Exhibit 6. OCSS Home Page



The OCSS Home page contains the following major categories of information:

OCSS Status of Registered Superstructures

The current status of registered superstructures in OCSS as described below:

Estimated – the number of superstructures with values entered into Umler that need to be reviewed by an auditor. All new superstructures are entered in “Estimated” status.

Verified – the number of superstructures with values entered into Umler that have been verified by an auditor.

Rejected – the number of superstructures with values entered into Umler that have been rejected by an auditor.

Pending – the number of superstructures with values entered into Umler that are pending audit review.

Total – the total number of estimated, verified, rejected, and pending superstructures with values entered into Umler.

Searching for and Viewing Cost Information


New Original Cost Status	<p>The current status of new original superstructures as described below:</p> <p>Estimated – the number of new original superstructures with values entered into Umler that need to be reviewed by an auditor. All new superstructures are entered in “Estimated” status.</p> <p>Pending – the number of new original superstructures with values entered into Umler that are pending audit review.</p> <p>Rejected – the number of new original superstructures with values entered into Umler that have been rejected by an auditor.</p> <p>Verified – the number of new original superstructures with values entered into Umler that have been verified by an auditor.</p>
Rebuilt Cost Status	<p>The current status of rebuilt superstructures as described below:</p> <p>Estimated – the number of rebuilt superstructures with values entered into Umler that need to be reviewed by an auditor.</p> <p>Pending – the number of rebuilt superstructures with values entered into Umler that are pending audit review.</p> <p>Rejected – the number of rebuilt superstructures with values entered into Umler that have been rejected by an auditor.</p> <p>Verified – the number of rebuilt superstructures with values entered into Umler that have been verified by an auditor.</p>

You can select any of the status values shown on the OCSS Home page and see a list of the superstructure IDs that meet the selected status (as though you had performed a search on the Management page using the status criteria). See “[Viewing Search Results](#)” on page 9 for more information.

Searching for Superstructures

To search for superstructures, select **Management** from the OCSS menu bar. The OCSS Management page is displayed ([Exhibit 7](#)).

Exhibit 7. OCSS Management Page (Showing the Search Equipment Criteria Fields)



The screenshot shows the OCSS Management page with the following search criteria fields:

- Home Management Documentation
- Search Equipment Criteria
- Equipment Initial
- Equipment Number
- SS ID
- Status: Estimated
- Cost Type: New
- Reset
- Search

Searching for and Viewing Cost Information

When initially displayed, the Management page shows the following Search Equipment Criteria fields:

Equipment Initial	The equipment initial (Mark) for the railcar on which the superstructure is mounted. If you do not enter an equipment initial, OCSS searches for superstructures owned by your logged in Mark. Note that the owner of the railcar may be different that the owner of the superstructure.
Equipment Number	The equipment number for the car on which the superstructure is mounted. If you specify an equipment number, you must also specify an equipment initial. You can enter a specific number or a range of numbers (e.g., 10000-24999). The range limit is 15,000 pieces of equipment.
SS ID	The superstructure ID.
Status	A drop-down list containing checkboxes for superstructure cost status values (Estimated, Pending, Rejected, and Verified). Select one or more status checkboxes.
Cost Type	A drop-down list that enables you to select whether to include new or rebuilt superstructures costs in your search results. Leave this field empty if you want to include all cost types in your search results.

Enter values in any of these fields and select **Search** to locate superstructures and view their information in the Search Results pane (see “[Viewing Search Results](#)” on page 9).

Note: You can select the caret (^) at the top right to hide the Search Equipment Criteria fields.

Viewing Search Results

The Search Equipment Result pane of the OCSS Management page ([Exhibit 8](#)) is displayed when you perform a search as described in “[Searching for Superstructures](#)” on page 8 or when you select any of the status values shown on the OCSS Home page as described in “[Viewing OCSS Status Information](#)” on page 7.

Exhibit 8. OCSS Management Page (Showing the Search Equipment Result Fields)

Search Equipment Criteria										
Search Equipment Result										
Showing 17 Equipment										
Enter Cost										
Refresh Export										
0 Selected										
Expand/Collapse										
	Initial and Number	SS ID	Last Update	Status	Built Month	Built Year	Rebuilt Month	Rebuilt Year	Original Cost	Total Costs
<input type="checkbox"/>	<input checked="" type="checkbox"/> RAIL0000600291			Estimated	February	2010	September	2023	\$ 4,000.00	\$ 2,190.70
<input type="checkbox"/>	<input checked="" type="checkbox"/> RAIL0000600003	556325		Estimated	February	2010	May	2023	\$ 4,000.00	\$ 2,235.10
<input type="checkbox"/>	<input checked="" type="checkbox"/> RAIL0000600091			Estimated	February	2010	September	2023	\$ 4,000.00	\$ 2,190.70
<input type="checkbox"/>	<input checked="" type="checkbox"/> RAIL0000600295			Estimated	February	2010	September	2023	\$ 4,000.00	\$ 2,190.70
<input type="checkbox"/>	<input checked="" type="checkbox"/> RAIL0000600044			Estimated	February	2010	September	2023	\$ 4,000.00	\$ 2,190.70
<input type="checkbox"/>	<input checked="" type="checkbox"/> RAIL0000043206	SOO 9170		Estimated	May	2019	October	2023	\$ 82,750.00	\$ 70,579.54
<input type="checkbox"/>	<input checked="" type="checkbox"/> RAIL0000600054			Estimated	February	2010	September	2023	\$ 4,000.00	\$ 2,190.70
<input type="checkbox"/>	<input checked="" type="checkbox"/> RAIL000004002	SOO 9170	10-17-2023 14:53:00	Estimated	May	2019	October	2023	\$ 82,750.00	\$ 70,579.54
<input type="checkbox"/>	<input checked="" type="checkbox"/> RAIL0000412045	SOO 9170		Estimated	May	2019	October	2023	\$ 82,750.00	\$ 70,579.54
<input type="checkbox"/>	<input checked="" type="checkbox"/> RAIL0000019239	SOO 9170		Estimated	May	2019	October	2023	\$ 82,750.00	\$ 82,750.00
<input type="checkbox"/>	<input checked="" type="checkbox"/> RAIL0000019340	SOO 9170		Estimated	May	2019			\$ 82,750.00	\$ 82,750.00
<input type="checkbox"/>	<input checked="" type="checkbox"/> RAIL0000994452	SOO 9170		Estimated	May	2019	October	2023	\$ 82,750.00	\$ 70,579.54
<input type="checkbox"/>	<input checked="" type="checkbox"/> RAIL0000019235	SOO 9170		Estimated	May	2019			\$ 82,750.00	\$ 82,750.00
<input type="checkbox"/>	<input checked="" type="checkbox"/> RAIL0000019236	SOO 9170		Estimated	May	2019			\$ 82,750.00	\$ 82,750.00
<input type="checkbox"/>	<input checked="" type="checkbox"/> RAIL0000019237	SOO 9170		Estimated	May	2019			\$ 82,750.00	\$ 82,750.00
<input type="checkbox"/>	<input checked="" type="checkbox"/> RAIL0000019341	SOO 9170		Estimated	May	2019			\$ 82,750.00	\$ 82,750.00
<input type="checkbox"/>	<input checked="" type="checkbox"/> RAIL0000019342	SOO 9170		Estimated	May	2019	October	2023	\$ 82,750.00	\$ 70,579.54

Searching for and Viewing Cost Information

The Search Equipment Result pane shows the equipment that matches the specified search criteria. It lists the number of displayed equipment at the top and contains the following columns of information:

Select the checkbox to the left of at least one piece of equipment to enter cost information for the selected pieces of equipment. See “[Entering Cost Information](#)” on page 13 for more information.

R If displayed to the left of an equipment initial and number, this icon indicates that the equipment has been rebuilt.

A&B If displayed to the left of an equipment initial and number, this icon indicates that the equipment has had an Addition and Betterment (A&B) added.


Initial and Number Identifies the railcar on which the superstructure is mounted. You can select an Initial and Number link to see the View Comments icon ()^{Comments}, which you can select to view the comments history for the selected equipment ([Exhibit 9](#)).

Exhibit 9. Comment History Popup



SS ID The superstructure ID.

Last Update The date on which cost information was last updated in OCSS for the associated equipment initial and number.

Status Indicates the status of the superstructure cost information currently in OCSS.

Built Month The month in which the superstructure was originally built.

Built Year The year in which the superstructure was originally built.

Rebuilt Month The month in which the superstructure was most recently rebuilt.

Rebuilt Year The year in which the superstructure was most recently rebuilt.

Original Cost The original cost of the superstructure.



Total Costs The total cost of the superstructure, including the costs of rebuilds, calculated in real-time (Reused Parts + New Net Cost).

Searching for and Viewing Cost Information

You can select **Expand/Collapse** in the header row to show and hide columns of information. This is especially useful when viewing information for rebuilt superstructures, which have the following additional columns of information:



A&B Date Done	The date of the individual Addition and Betterment.
A&B Code	Rack Indicator for Positive/Negative A&B.
Ledger Value	The sum of the Original Cost and Additions and Betterments.
Reused Parts	Calculated as the Ledger Value multiplied by the Reused Percentage.
Reused Percentage	The calculated reused percentage.
Effective Reused Percentage	The effective reused percentage, taking into consideration the cap of 10%. If the calculated reused percentage is less than 10%, 10% is used instead.
Rebuilt Materials	Refer to your supporting documentation (e.g., invoice) for this field.
Rebuilt Material Additional	Refer to your supporting documentation (e.g., invoice) for this field.
Rebuilt Labor	Refer to your supporting documentation (e.g., invoice) for this field.
Less Stripping	Refer to your supporting documentation (e.g., invoice) for this field.
Less Material Credit	Refer to your supporting documentation (e.g., invoice) for this field.
Invoiced	Sum of Rebuilt Material + Rebuilt Material Additional + Rebuilt Labor.
New Net Cost	Invoiced Amount minus Less Stripping minus Less Material Credit.
New Original Cost	Invoiced Amount minus Less Stripping minus Less Material Credit.

You can sort any column by selecting the header in that column. An arrow to the right of the column header indicates the direction of the sort. Select the header a second time to change the direction of the sort. You can sort by multiple columns by holding the Shift key and selecting an additional column header. A number to the right of the column header indicates precedence of a multi-column sort.

You can also filter any column by selecting the menu icon () to the right of a column header and then using the filter options to narrow the search results. Once you apply a filter to a column, a filter icon () is displayed to the right of the column header. To remove a filter, select the menu icon and delete the contents of the filter field.

Searching for and Viewing Cost Information

The Search Equipment Result pane also contains the following icons and buttons:

- | | |
|------------|---|
| Refresh | Select the refresh icon ( Refresh) at the top right of the Search Equipment Result page to update the search results with current information. You may want to select this button if the search results information has been displayed on your screen for an extended period of time or when you are expecting information to be updated in Umler. |
| Export | Select the export icon ( Export) at the top right of the Search Equipment Result page to download the currently displayed list of search results as a CSV file – up to 100,000 rows. There is no charge for downloading these results. Any filters that have been applied to the search results are also reflected in the downloaded file. |
| Enter Cost | Select the checkbox for at least one piece of equipment and then select Enter Cost to enter cost information for the selected piece(s) of equipment. See “ Entering Cost Information ” on page 13 for more information. |

Entering Cost Information

OCSS enables you to submit documentation to support the original cost information as well as rebuilt cost information that is entered in Umler. OCSS also enables you to submit information and supporting documentation for an Addition and Betterment (A&B), which is an addition to a superstructure that was made after it was built (e.g., the addition of a ladder).

See the following sections for more information:

- [“Entering Original Cost Information”](#) on page 13
- [“Entering Addition and Betterment \(A&B\) Information”](#) on page 15
- [“Entering Rebuilt Cost Information”](#) on page 17

Entering Original Cost Information

When viewing search results as described in [“Viewing Search Results”](#) on page 9, you can select the checkbox for at least one piece of equipment and then select **Enter Cost** to enter original cost information for the selected piece(s) of equipment. The Enter Cost popup is displayed ([Exhibit 10](#)).

Exhibit 10. Enter Cost Popup (Showing the Enter Cost Section)

Equip ID	SS ID	<input type="checkbox"/> Original Cost	<input type="checkbox"/> A&B Date Done	<input type="checkbox"/> A&B Indicator	<input type="checkbox"/> A&B Cost
RAIL0000019340	SOO 9170	\$ 82,750			\$ 0

To submit documentation to support the original cost information that is entered in Umler, simply review the existing cost information in the Enter Cost section and select **Next**. The Enter Cost popup proceeds to the Upload Documents section ([Exhibit 11](#)).

You can modify the information in the Original Cost field if the new values are supported by the documentation you are uploading.

If you are modifying information for multiple equipment ID’s, you can apply the values in the top row to all equipment in the list by checking the boxes at the top of the columns.


Notes:

- The Original Cost must be between \$4000 and \$175,000.

Entering Cost Information


- If you make changes to the values in the Original Cost column for a superstructure, you cannot enter A&B information for that superstructure. Similarly, if you make changes to the values in any of the A&B columns for a superstructure, you cannot enter Original Cost information for that superstructure.
- Select **Delete** to delete a submission that is in pending or rejected status.
- Select **Reset** to return all of the entered values to the values saved in OCSS.

Exhibit 11. Enter Cost Popup (Showing the Upload Documents Section)



Select **Browse File** and locate a file containing invoice information to support the original cost of the superstructure. PDF is the only supported file type. The Upload Documents section of the Enter Cost popup lists the selected file ([Exhibit 12](#)).


Exhibit 12. Enter Cost Popup (Showing the Upload Documents Section Completed)



You can add multiple files if needed. To remove a file, select the Trash Can icon ().

Select **Submit** to submit the uploaded document(s) as supporting documentation for the original cost of the superstructure. If successful, a success message is displayed ([Exhibit 13](#)).

Exhibit 13. Enter Cost Success Message




Note: If you selected multiple equipment ID's, you can verify all of the costs for the selected equipment, and then upload one set of supporting documents for all of the equipment.

Entering Addition and Betterment (A&B) Information

When viewing search results as described in "[Viewing Search Results](#)" on page 9, you can select the checkbox for at least one piece of equipment and then select **Enter Cost** to enter Addition and Betterment (A&B) information for the selected piece(s) of equipment. The Enter Cost popup is displayed ([Exhibit 14](#)).

Exhibit 14. Enter Cost Popup (Showing the Enter Cost Section)

A screenshot of the "Enter Cost" popup window. The window has a title bar with "Enter Cost" and a close button. Below the title bar, there are two tabs: "Enter Costs" (active) and "Upload Documents". The main content area contains a table with columns for "Equip ID", "SS ID", "Original Cost", "A&B Date Done", "A&B Indicator", and "A&B Cost". Each column has a checkbox above it. The table has one row of data: Equip ID: RAIL0000019239, SS ID: SOO 9170, Original Cost: \$ 82,750, A&B Date Done: 11/27/2023, A&B Indicator: P - Positive, A&B Cost: \$ 12,000. At the bottom of the form, there are buttons for "Next", "Reset", and "Delete".


OCSS is used to create and modify Addition and Betterment (A&B) information. You can add information in the A&B fields (A&B Date Done, A&B Indicator, and A&B Cost) if the new values are supported by the documentation you are uploading. Review the cost information and select **Next**. The Enter Cost popup proceeds to the Upload Documents section ([Exhibit 15](#)).

If you are modifying information for multiple equipment ID's, you can apply the values in the top row to all equipment in the list by checking the boxes at the top of the columns.

Notes:


- The A&B amount must be less than or equal to \$50,000.
- If you make changes to the values in the Original Cost column for a superstructure, you cannot enter A&B information for that superstructure. Similarly, if you make changes to the values in any of the A&B columns for a superstructure, you cannot enter Original Cost information for that superstructure.
- Select **Delete** to delete a submission that is in pending or rejected status.
- Select **Reset** to return all of the entered values to the values saved in OCSS.

Exhibit 15. Enter Cost Popup (Showing the Upload Documents Section)



Select **Browse File** and locate a file containing invoice information to support the original cost of the superstructure. PDF is the only supported file type. The Upload Documents section of the Enter Cost popup lists the selected file ([Exhibit 16](#)).


Exhibit 16. Enter Cost Popup (Showing the Upload Documents Section Completed)



You can add multiple files if needed. To remove a file, select the Trash Can icon ().

Select **Submit** to submit the uploaded document(s) as supporting documentation for the original cost of the superstructure. If successful, a success message is displayed ([Exhibit 17](#)).

Exhibit 17. Enter Cost Success Message



Note: If you selected multiple equipment ID's, you can verify all of the costs for the selected equipment, and then upload one set of supporting documents for all of the equipment.

Entering Rebuilt Cost Information

When viewing search results as described in “[Viewing Search Results](#)” on page 9, you can select the checkbox for at least one piece of equipment and then select **Enter Cost** to enter rebuilt cost information for the selected piece(s) of equipment. The Enter Cost popup is displayed ([Exhibit 18](#)).

Exhibit 18. Enter Cost Popup (Showing the Enter Cost Section)

Equip ID	SS ID	Rebuilt Material	Rebuilt Material Add.	Rebuilt labor	Less Stripp	Total Costs
RAIL0000004002	SOO 9170	\$ 0.00	\$ 0.00	\$ 0.00	\$ 0.00	\$ 70,580.00

To submit documentation to support the rebuilt cost information, review the existing cost information in the Enter Cost section and complete the fields needed for the rebuilt superstructure. Select **Next** when you have finished.


The Enter Cost popup proceeds to the Upload Documents section ([Exhibit 19](#)).

If you are modifying information for multiple equipment ID’s, you can apply the values in the top row to all equipment in the list by checking the boxes at the top of the columns.

Notes:


- The Rebuilt Cost must be between \$4000 and \$175,000.
- Select **Delete** to delete a submission that is in pending or rejected status.
- Select **Reset** to return all of the entered values to the values saved in OCSS.


Exhibit 19. Enter Cost Popup (Showing the Upload Documents Section)



Select **Browse File** and locate a file containing invoice information to support the rebuilt cost of the superstructure. PDF is the only supported file type. The Upload Documents section of the Enter Cost popup lists the selected file ([Exhibit 20](#)).

Exhibit 20. Enter Cost Popup (Showing the Upload Documents Section Completed)



You can add multiple files if needed. To remove a file, select the Trash Can icon ().

Note: If you selected multiple equipment ID's, you can verify all of the costs for the selected equipment, and then upload one set of supporting documents for all of the equipment.

Select **Submit** to submit the uploaded document(s) as supporting documentation for the rebuilt cost of the superstructure. If successful, a success message is displayed.

A successful update of rebuilt cost information clears the following superstructure A&B fields in Umler: SS Indicator A&B (A296), SS Addition & Betterment (A004), and SS A&B Done Date (B599). The Original Cost is also updated with the Total Costs value.